

Specific directions for NPC- installation to **Micros-Fidelio VSS 3700**

Each point-of-sale with the installed and activated **VSS** service for the transmission of transaction data via the network sends booking data to a previously configured target (**NPC**) via the LAN (Local Area Network, in this case the point-of-sale network). Whether the desired point-of-sale has the necessary **VSS** service at its disposal should be clarified with or requested from the supplier responsible for the points-of-sale in advance

Configuration cash register / VSS 3700:

First configure the affected points-of-sale using the **VSS 3700-Configurator** program:

- It is recommended that you activate the setting **Individual server for every workstation** during this.
- In the **Workstations** menu that is then listed, it is only possible to allocate points-of-sale and NPCs.
(You need for each desired cash register one NPC!)
- Each point-of-sale/workstation with the desired data capture can now be activated via the **VSS active** item.
- To the right of this, the target IP (not the IP address of the point-of-sale network!) of the **NPC** is to be entered.
- As a remote port, a number of no more than four digits should be entered; standard port of the **NPC 2315**.
- Please make a note of or remember the last two digits of the workstation-ID on the left (nine digits in total) for later entry at the NPC!

Configuration NPC:

The **NPC** is connected to the point-of-sale network via the **Ethernet** interface. Allocate a free IP address to the **NPC** within the point-of-sale network and retain the port number **2315**.

The point-of-sale number (the last two digits of the workstation-ID) to the desired NPC has to be entered.

File name: **Micros_3700.npc**